

Instruction manual Tembo 4x4 Rooftop tent




TEMBO 4X4 ROOFTOP TENT

The concept of our rooftop tents is based on more than 15 years' experience in the use, production & selling of rooftop tents. The safety factor and advantage as a lookout position and easy set-up have made rooftop tents very popular.

The ability to test the Tembo 4x4 rooftop tent in the field, over rough terrain and in all-weather conditions worldwide, has enabled us to produce a rooftop tent of strength and reliability in a competitive price range.

Wake up feeling fresh and alive after a good night's sleep on a high-density foam mattress, standard in every Tembo 4x4 Rooftop Tent!

PARTS:



x1

1×Rooftop Tent
(Tent & Foam mattress)



x1

1×Ladder
(2x 1.9 tents)



x2

2 x Aluminum bar



x1

1×Travel Cover



x2

2×Sets for ladder



x4

4×sets for Aluminum bar



x8

8× Wires



x8

8×Screw



x2

2×Wrench



x1

1×Instruction manual




1×Spreader bar
(tourer version only)


INSTALLATION MANUAL:

Step 1. Open the tent and take out all accessories.


Step 2. Fix the aluminum bar under the bed base using the predrilled openings




Step 3. Fix the ladder to the tent base using the openings under the bed base




Step 4. Choose the direction in which you want to open the tent




Open the tent to the right side:




Open the tent to the back:



Step 5. Slide the top & bottom cover in the bed base



Step 6. Zip up the cover and fasten all straps



OPERATION INSTRUCTIONS:

Step 7. Unfasten the straps, unzip the travel cover and stretch the ladder



Step 8. Open the tent by pulling the ladder, and adjust the ladder to a suitable position



Step 9. Lock both pins of the ladder before entering the tent. Always use the ladder extension part so all ladder segments have enough overlap



Step 10. Set up the window & door flap using the springs

Please note: Place the springs in the small drilled holes in the frame of the bed and trough the gap of the tent fabric before hooking them in the rings on the flaps.



Step 11. Pull down the tent fabric on the corners of the tent, so water can glide off the tent.

Step 12. Remove the elastic cords inside the tent. (used for packing up the tent)




Step 13. (Tourer version only) Place the U-shaped pole in the top corner of the extension part first and insert them into the brackets at the bed base.



Step 14. Fit the spreader bar through the gap, click it on the tent frame and extend the spreader bar.

Please note: before using the rooftop tent for the first time, spray water on the tent. The water will make the threads swell up in the seams and the seams will fill the small holes created by the needle and it tightens the fabric, making it watertight.

OPTIONAL: Annex tent



Peg×4

Annex×1

Slide the annex tent in the bed base, adjust it to a suitable position, fasten the straps to the ladder and fix 4 pegs into the earth.

Cleaning the tent:

Spread the tent fabric and spray it with cold water using a shower nozzle and scrub the tent gently with a small brush or cloth. if necessary, put a little bit of neutral detergent to clean (do not use cleaning products!). Do not put the tent in the washing machine to clean, because this will damage the seam-tape and water resistance of the tent.

PLEASE NOTE:

Do not move the vehicle when the rooftop tent is set up.

Be aware of the height of your vehicle when the rooftop tent is fitted on top.

110km/h Speed limit to avoid excessive wear on the travel cover

After the first times the tent gets wet the seams will heal

Max load of tent base: 300kg (depends on the vehicle itself at the top of the load-bearing)

Wind force 5 is the maximum wind force for using the Rooftop tent

Please dry the tent as soon as possible after a rainy day, do not pack the tent when it is wet.

Always use guy ropes (and a spreader pole on a tourer version) to prevent rain to collect on top.